Gliderol TM305c Coding Instructions







Compatible TM305c Genuine TM305c

Active TM305c

Programming Your Remote Into the Motor

- 1 Carefully remove the cover from the control box by lifting the tab at the bottom
- 2 Press the receiver button once, and a red light will illuminate
- 3 Press the large button on the transmitter once, and hold until the red light turns off
- 4 Test the operation of your new remote

Clearing The Codes From Your Motor

- 1 Press and hold the receiver button for 12 seconds
- 2 Test that your remote no longer operates the motor



